


COOLING FAN RELAY INSPECTION

AC28U-03


- 1. REMOVE COOLING FAN RELAYS NO. 1 AND NO. 2 FROM ENGINE ROOM RELAY BLOCK**



- 2. INSPECT NO. 1 COOLING FAN RELAY (Marking: FAN1) CONTINUITY**

Condition	Tester connection	Specified condition
Constant	1 - 2	Continuity
Apply B+ between terminals 1 and 2	3 - 5	Continuity

If continuity is not as specified, replace the relay.



- 3. INSPECT NO. 2 COOLING FAN RELAY (Marking: FAN2) CONTINUITY**

Condition	Tester connection	Specified condition
Constant	1 - 2 3 - 4	Continuity
Apply B+ between terminals 1 and 2	3 - 5	Continuity

If continuity is not as specified, replace the relay.

- 4. INSTALL COOLING FAN RELAYS NO. 1 AND NO. 2 FROM ENGINE ROOM RELAY BLOCK**