


COOLING FAN RELAY INSPECTION

COOVA-02


1. INSPECT NO. 1 COOLING FAN RELAY

- Remove the relay box cover.
- Remove the No. 1 cooling fan relay. (Marking: FAN NO. 1)




- Inspect the No. 1 cooling fan relay continuity.
 - Using an ohmmeter, check that continuity exists between terminals 1 and 2.
- If no continuity exists, replace the relay.
- Check that no continuity exists between terminals 3 and 5.

If continuity exists, replace the relay.




- Inspect the No. 1 cooling fan relay operation.
 - Apply battery voltage across terminals 1 and 2.
 - Using an ohmmeter, check that continuity exists between terminals 3 and 5.
- If no continuity exists, replace the relay.
- Reinstall the No. 1 cooling fan relay.
 - Reinstall the relay box cover.




2. INSPECT NO. 2 COOLING FAN RELAY

- Remove the relay box cover.
- Remove the No. 2 cooling fan relay. (Marking: FAN NO. 2)



- Inspect the No. 2 cooling fan relay continuity.
 - Using an ohmmeter, check that continuity exists between terminals 1 and 2.
- If no continuity exists, replace the relay.
- Check that continuity exists between terminals 3 and 4.
- If no continuity exists, replace the relay.
- Check that no continuity exists between terminals 3 and 5.
- If continuity exists, replace the relay.



(d) Inspect the No. 2 cooling fan relay operation.

(1) Apply battery voltage across terminals 1 and 2.

(2) Using an ohmmeter, check that no continuity exists between terminals 3 and 4.

If continuity exists, replace the relay.

(3) Using an ohmmeter, check that continuity exists between terminals 3 and 5.

If no continuity exists, replace the relay.

(e) Reinstall the No. 2 cooling fan relay.

(f) Reinstall the relay box cover.