


## REPLACEMENT

### REPLACE CRANKSHAFT FRONT OIL SEAL

- (a) Using a knife, cut off the oil seal lip.
- (b) Using a screwdriver, pry out the oil seal.

#### NOTICE:

Be careful not to damage the crankshaft. Tape the screwdriver tip.



- (c) Using SST and a hammer, tap in the oil seal until its surface is flush with the timing chain cover edge.

SST 09612-2201 1