


INSTALLATION

NOTICE:

Never use airbag parts from another vehicle. When replacing parts, replace them with new parts.

HINT:

For step 2 to 7, refer to page [BO-84](#).




1. INSTALL FRONT PASSENGER AIRBAG ASSEMBLY

- (a) Install the front passenger airbag assembly to the instrument panel.
- (b) Install the 2 nuts.

NOTICE:

If the front passenger airbag assembly has been dropped, or there are cracks, dents or other defects in the case or connector, replace the front passenger airbag assembly with a new one.


2. INSTALL INSTRUMENT PANEL
3. INSTALL CLUSTER FINISH PANEL
4. INSTALL NO. 1 AND NO. 2 SPEAKER PANEL
5. INSTALL FRONT PILLER GARNISHES
6. INSTALL COMBINATION METER
7. INSTALL CLUSTER FINISH PANEL



8. FIX FRONT PASSENGER AIRBAG ASSEMBLY

Install the bolt to the instrument panel reinforcement.

Torque: 18 N·m (185 kgf-cm, 13 ft-lbf)



9. CONNECT AIRBAG CONNECTOR

- (a) Connect the connector of the front passenger airbag assembly.
- (b) Install the connector cover to the lower instrument panel.
- (c) Install the glove compartment door.