


REMOVAL

NOTICE:

- If the wiring connector of the SRS is disconnected and the ignition switch is in ON position, DTCs will be recorded.
- Never use the airbag parts from another vehicle. When replacing parts, replace them with new parts.

HINT:

For step 2 to 7, refer to page [BO-76](#) .



1. DISCONNECT AIRBAG CONNECTOR

- Remove the glove compartment door.
- Remove the connector cover from the lower instrument panel.

NOTICE:

When handling the airbag connector, take care not to damage the airbag wire harness.

- Disconnect the front passenger airbag connector.

2. REMOVE CLUSTER FINISH PANEL


3. REMOVE COMBINATION METER

4. REMOVE FRONT PILLER GARNISHES

5. REMOVE NO. 1 AND NO. 2 SPEAKER PANEL

6. REMOVE CENTER CLUSTER FINISH PANEL

7. REMOVE INSTRUMENT PANEL



8. REMOVE FRONT PASSENGER AIRBAG ASSEMBLY

- Remove the 2 nuts and pry up the 6 clips.
- Remove the front passenger airbag assembly.

CAUTION:

- Do not store the front passenger airbag assembly with the airbag deployment side facing downward.
- Never disassemble the front passenger airbag assembly.