



INSTALLATION

1. PLACE THERMOSTAT IN CYLINDER BLOCK

- (a) Install a new gasket to the thermostat.
- (b) Install the thermostat with the jiggle valve upward.

HINT:

The jiggle valve may be set within 10° at either side of the prescribed position.

2. INSTALL WATER INLET

- (a) Install the water inlet with the 2 nuts.
- (b) Install the wire harness to the water inlet.

Torque: 9.0 N·m (90 kgf·cm, 80 in.-lbf)

3. FILL WITH ENGINE COOLANT

4. START ENGINE, AND CHECK FOR COOLANT LEAKS.