

## INSTALLATION

### 1. INSTALL SHOCK ABSORBER WITH COIL SPRING

- (a) Install the shock absorber with coil spring and 3 nuts.

**Torque: 39 N·m (400 kgf·cm, 29 ft·lbf)**

- (b) Connect the shock absorber to the steering knuckle.

- (c) Coat the threads of the 2 nuts with engine oil.

- (d) Install the 2 bolts and nuts.

**Torque: 132 N·m (1,350 kgf·cm, 97 ft·lbf)**

### 2. CONNECT ABS SPEED SENSOR WIRE HARNESS CLAMP AND FLEXIBLE HOSE TO SHOCK ABSORBER

**Torque: 29 N·m (300 kgf·cm, 22 ft·lbf)**

### 3. INSTALL FRONT WHEEL

**Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)**

### 4. CHECK FRONT WHEEL ALIGNMENT (See page [SA-5](#))