

# AIR CONDITIONER UNIT

## ON-VEHICLE INSPECTION

AC283-01

### INSPECT FOR LEAKAGE OF REFRIGERANT

- (a) Remove the glove compartment door (See page [BO-76](#) ).
  - (b) Remove the blower resistor.
  - (c) Using a gas leak detector, check for leakage of refrigerant.
- If there is leakage, check the tightening torque at the joints or check the evaporator.