

## INSTALLATION

Installation is in the reverse order of removal (See page [BR-12](#) ).

HINT:

- Before installation, adjust length of brake booster push rod (See page [BR-16](#) ).
- After installation, fill the brake reservoir with brake fluid and bleed brake system (See page [BR-4](#) ).
- Check for leaks, check and adjust brake pedal (See page [BR-6](#) ).