


ANTI-LOCK BRAKE SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

DI6SE-03

Troubleshoot in accordance with the procedure on the following pages.



Fail safe function:

In the event of a malfunction in the ABS system, the ABS ECU turns on the ABS warning light and prohibits the ABS control.