
























# ENGINE MECHANICAL

## SST (Special Service Tools)

PP2FA-02

	09032-00100	Oil Pan Seal Cutter	
	09201-01055	Valve Guide Bushing Remover & Replacer 5.5	
	09201-41020	Valve Stem Oil Seal Replacer	
	09202-70020	Valve Spring Compressor	
	(09202-00010)	Attachment	
	09213-7001 1	Crankshaft Pulley Holding Tool	
	09221-25026	Piston Pin Remover & Replacer	
	(09221-00021)	Body	
	(09221-00030)	Spring	
	(09221-00141)	Guide H	
	(09221-00150)	Bushing "D"	
	(09221-00190)	Guide "K"	

PREPARATION - ENGINE MECHANICAL

	<p>09222-30010 Connecting Rod Bushing Remover &amp; Replacer</p>	
	<p>09223-15030 Oil Seal &amp; Bearing Replacer</p>	
	<p>09330-00021 Companion Flange Holding Tool</p>	
	<p>09612-2201 1 Tilt Handle Bearing Replacer</p>	
	<p>09950-50013 Puller C Set</p>	
	<p>(09951-05010) Hanger 150</p>	
	<p>(09952-05010) Slide Arm</p>	
	<p>(09953-05020) Center Bolt 150</p>	
	<p>(09954-05021) Claw No.2</p>	
	<p>09950-70010 Handle Set</p>	
	<p>(09951-07100) Handle 100</p>	